



DO NOT DRAG
2 MAN LIFT

Genoa



Wardrobe

Assembly instruction




IMPORTANT: RETAIN FOR FUTURE REFERENCE:
READ CAREFULLY




















IND. 4020419

BEFORE ASSEMBLY:


MAIN COMPONENTS

- unpack all the parts and identify them against the fittings and components list.
- do not discard any packaging until you have checked that you have all parts as shown below.
- you may find the construction of your dresser easier if you have the help of another person.
- crosshead screwdriver (not provided)





1000806		x 1	1006022		x 12	1005857		x 12
1005367		x 20	1006091		x 20	1103814		x 6
1006012		x 11	1000893		x 1	1001262		x 8
1104028		x 6	1006031		x 6	1002152		x 1
1005681		x 12	1110778		x 4	1000225		x 4
1005876		x 4	1005926		x 2	1122724		x 3
1005962		x 14						

EN. In case of complain please advise the spare part number.


ARTIKELNUMMER		4020419	QUANTITY ANZAHL	DIMENSIONS [mm] ABMESSUNGEN [mm]		
1	2/4	2204236	2	900	540	22
2	2/4	2204207	1	900	540	22
3	3/4	2204208	1	1582	539	16
4	3/4	2204209	1	1582	539	16
5	1/4	2204210	1	866	507	16
6	1/4	2204211	1	866	150	16
7	1/4	1122725	4	141	59	38
8	1/4	2204212	2	866	505	16
9	4/4	2204213	2	861	217	16
10	1/4	2204215	1	400	150	16
11	1/4	2204216	1	400	150	16
12	4/4	2204217	1	809	129	16
13	1/4	2204218	1	822	405	2,5
14	4/4	2163706	1	1444	878	2,5
15	4/4	2204213	2	809	129	16
16	1/4	1109139	2	853	—	—

1




2

1005367




x 3

1103814




x 3

1005857




x 2




3

1006091




x 4




4

1005367




x 3

1103814




x 3

1005857




x 2




5

1005367






x 6

1005857




x 4




6

1005857









x 4


1005367





x 2



7



8



9


WARNING!
 IN ORDER TO PREVENT OVERTURNING
 THIS PRODUCT MUST BE USED WITH
 THE WALL ATTACHMENT DEVICE
 PROVIDED

Detonics or fatal crushing injuries can occur from
 random tipping over. To help prevent tipping over:



- Use the wall attachment device provided
- Never allow children to climb or hang on
 drawers, doors or shelves
- Place heaviest items in the lower drawers
 or shelves
- Shelves specifically designed to
 accommodate, do not set TV's or other
 heavy objects on top of this product
- Never open more than one drawer at a
 time

An attachment device is provided with your product.
 However you will need to secure multiple fasteners for your
 wall type. For details, please consult a qualified
 professional.


Always ensure the wall to be drilled is free from hollow





10




11



1005962 x 6




12




1006091 x 8


13



14




1001262




x 8


15



16



1006022







x 12


1006012




x 6



19




20




17

1000225





x 4

1110778



x 4





18


16






16





21




22











23






CLICK





i



24




25




26

1005876




x 4




27


1006091




x 4



28



29




30

1006012




x 5



31

1005926




x 2



1002152







x 1



32



33



Safety

Always use the wall attachment strap provided.

All assembly fixings should always be tightened properly. Care should be taken that no screws are loose because a child could trap parts of their body, or clothing (e.g. strings, necklaces, ribbons, dummies, etc.) which could pose a risk of strangulation.

Be aware of the risks of open fires and other such sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the wardrobe.

Do not use if any of the parts are broken, torn or missing.

Any additional or replacement parts can only be obtained from the manufacturer or the distributor.

ensure there are no small parts fittings are left after assembly as these can be a choking hazard.

Maintenance

Take care when handling or moving the furniture. Careless handling may cause damage.

Regularly check that all fixings are tightened and that there are no broken or damaged parts.

Cleaning

Your wardrobe can be cleaned by wiping with a damp cloth and drying with a soft clean cloth. Do not use abrasives, bleach, alcohol or ammonia based household polishes.

Little Acorns

01952460696 and address:

The Malthouse,

Sheriffhales, Shifnal.

Shropshire TF11 8RD