


JOHN  
LEWIS  
& PARTNERS

# Deluxe Rocking Stand

Stock number: 32453001 & 32453002



IMPORTANT RETAIN FOR FUTURE REFERENCE READ CAREFULLY

H 53 W 61 L 85cm

Thank you for purchasing this Deluxe Rocking Stand. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Your child's safety is your responsibility. If you have a query with this product or require replacement parts, please contact your nearest John Lewis department store.

Lay out the parts on a soft level surface and compare to the part/ fixings checklist on page 3.



Do not discard any packaging until you are sure that you have all the parts.

Keep children clear during assembly as pack contains small parts which may present a choking hazard.

This product complies with BS EN 1466:2014

The John Lewis team


## Tools required



Time to assemble

15-30 minutes

People to assemble



# Important Safety information

## Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

## Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

## Don'ts

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.



# Your Deluxe Rocking Stand



Ref	Description	Dimensions	Qty
1	Right leg	46.6cm	2
2	Left leg	46.6cm	2
3	Front rocker	61cm	1
4	Back rocker	61cm	1
5	Basket support rail	38cm	2
6	Bottom rail	50cm	2
7	Top rail	50cm	1
8	Flexible Strap	60cm	2
9	Circular Stabiliser	4.4cm	4

Stand Overall Size: H 53 W 61 L 85cm  
 Stock number : 32453001 & 32453002

# Fixtures and fittings

Fixtures and fittings  
supplied (actual size)

Ref	Description	Dimensions	Qty	mm
A	Philips head screw	50mm	12	
B	Philips head screw	40mm	8	
C	Philips head screw	15mm	4	
D	Philips head screw	16mm	4	
E	Barrel screw	18mm	4	
F	Rod	18mm	8	


# Product assembly

Deluxe Rocking Stand

## Step 1

Parts, fittings and tools

1 2 5 A F




## Step 2

Parts, fittings and tools

3 4 A F

### Important:


Ensure hole recess in leg and guidelines on the rocker are facing the same way as shown in the diagram



## Step 3

Parts, fittings and tools

9 E D




# Product assembly

Deluxe Rocking Stand

## Step 4

Parts, fittings and tools

6 7 B



### Important:



Ensure the rods with staples side of Part 7 is facing downward.  
Make sure rods are pushed fully into rod recesses.

## Step 5

Parts, fittings and tools

8 C

**Important:** Stabilisers 9 must be in locked position when stand is unattended.



## Care and maintenance

Stand - If necessary, wipe with damp cloth

Dispose of all packaging safely before use. Complies with BS EN 1466: 2014

## Safety notes

This product is suitable only for a child who cannot sit up unaided, roll over, and cannot push itself up on its hands and knees. Maximum weight of the child: 9 kg

Ensure the moses basket is held securely by the end straps. Use the 3 holes on the end straps to provide adjustment. Check carefully that the moses basket is secure in the rocking stand before use.

After assembly, please re-check to ensure that all screws are tightened securely before use.

Please check and retighten the stabilisers regularly to ensure the proper locking function.

WARNING: Only use on a firm ground which is horizontal, level and dry

WARNING: Do not let other children play unattended near the carry cot and stand

WARNING: Do not use if any part of the stand is broken, torn or missing

WARNING: Do not attach anything to the stand, which may affect its stability

Only use replacement parts supplied or approved by the manufacturer

Do not place the stand near an open fire or other source of strong heat

When the stand is not in use, it should be stored away from children

The stand is designed for use with a palm or wicker moses basket of min/max 700-835mm in length and 300-370mm in width.

Do not add another mattress on top of the mattress provided or recommended by John Lewis