

Product information

- Indoor use only
- 3 step dimmable
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish
- This product contains Li-ion batteries

Aftercare and Troubleshooting

Please note the touch sensor will use a small amount of current at all times and will slowly drain the battery even when the light is off.

If you find the lamp turning itself off, even when the product is put on charge, it means the battery has been almost completely drained and needs initial charging before the lamp can be switched on again. Please refer to Step 4.

If there are technical issues with this product that you are unable to resolve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.

Specification

Max power: 1.4W

2700K 171Lm

INPUT Max.: 10W DC 5V 2A

Battery: 3.7V 3600mAh

IP rating: 20

Weight: 0.86kg

Charging time: 4 hours when fully discharged

Time in use: 7 hours on full brightness

Separate supply unit



Direct current



Non-replaceable light source

2-year guarantee

At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 2-year guarantee.

Recycling

This symbol indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

John Lewis plc
SW1V 2QQ
johnlewis.com

Made in China




19/04/2024

Please retain these instructions for future reference.



CARLITA TOUCH TABLE LAMP USER GUIDE



70600443
70676613

Getting started

Thank you for purchasing this John Lewis & Partners product. For your safety, and to make sure everything is working properly, please read the instructions carefully before use.

Warnings

This product is battery powered and the internal battery is recharged via a supplied USB-A to USB-C cable.

This product should only be connected to equipment of Class II or class III.

Batteries are only to be charged by persons over 8 years of age.

Only charge via a input max. 10W DC 5V 2A plug-in adapter (phone charger or similar USB outlet).

This product is for indoor use only, and not suitable for a bathroom or outdoor location.

Do not plug this product directly into the mains or by other means other than the supplied cable.




This product is not suitable for children under 3 years of age.

The battery must not be opened, destroyed or incinerated.

The battery in this product is non-replaceable and if damage occurs must be disposed of responsibly.

The light source in this product is non-replaceable and if damage occurs, the product should be scrapped.

Parts list

Description	Image	Quantity
Light fitting		x 1
Shade		x 1
USB cable		x 1

Product assembly

Step 1

Carefully unpack the carton, making sure all the parts are present before assembly.

Step 2

This lamp should be assembled by an adult. To attach the shade, gently push the shade clips (A) inside the shade onto the bulb.

Step 3

Connect the USB cable to the product (B) and to a USB outlet (C) (phone charger or similar USB outlet rated input max. 10W DC 5V 2A).

Step 4

Charge the battery before first use. Ensure the product is fully charged before operating. The light indicator on button (D) will turn from red to green when fully charged. Your table lamp is now ready for use.

To operate the on/off dimmer, just touch the button. (one touch brightest, second touch brighter, third touch low light level and fourth to turn off).

When used on the brightest setting the light will start to dim after 6-7 hours of use.

Top up the battery by charging the lamp until the light turns green.

Always unplug after charging. Do not use while charging to extend battery life.

