


ANYDAY

JOHN LEWIS
& PARTNERS

Anyday Wood 2 Seat Lounge Set User Guide



Product code:
82034211

Thank you for purchasing the Anyday Wood 2 Seat Lounge Chair. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

At John Lewis, we are committed to making great products possible.


From our in - house Design Team, to our Buyers, we work together to bring great design to life.

Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell.

We are all committed to designing and developing products to the highest industry standards. We hope you are happy with your product and welcome any feedback or comments you may have.


The John Lewis Team

Tools required



Time to assemble
20 Min

People to assemble



Important safety information

Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Spare parts are available, please contact our Furniture Aftercare Team on 03456 049 049 if you need assistance
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

Don'ts

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.



Your chair and table



Ref	Description	Dimensions			Qty
1	Back	H5	W63.5	D71 cm	2
2	Seat	H5	W45	D57.5 cm	2
3	Right Legs	H2.2	W55	D60 cm	2
4	Left Legs	H2.2	W55	D60 cm	2
5	Seat cushion	H7	W53	D55 cm	2
6	Back cushion	H7	W45	D60 cm	2
7	Table top	H2	W45	D35 cm	1
8	Leg Frame	H2	W37	D34 cm	2
9	Crossbar	H2	W39	D3.5cm	1


Internal dimensions

Stock Number: 82034211

Chair: H72 W60 D64cm

Table: H39 W45 D35cm

Fixtures and Fittings



Fixtures and Fittings

supplied (actual size)

Ref	Description	Dimensions	Qty	<div>mm<div>0102030405060708090100</div></div>
A	Bolt	M6 x 55mm	4	
B	Bolt	M6 x 60mm	15	
C	Dowel Nut	M6 x 13mm	14	

Internal dimensions
Stock Number: 82034211
Chair: H72 W60 D64cm
Table: H39 W45 D35cm


Product assembly

Anyday Wood 2 Seat Lounge Set

Step 1

Parts, fittings and tools

2 3 4 B C




x2

Step 2

Parts, fittings and tools

1 A



Internal dimensions

Stock Number: 82034211

Chair: H72 W60 D64cm

Table: H39 W45 D35cm

x2


Product assembly

Anyday Wood 2 Seat Lounge Chair

Step 3

Parts, fittings and tools


5 6



x2

Step 4 Final Assembly

Parts, fittings and tools



Internal dimensions

Stock Number: 82034211

Chair: H72 W60 D64cm

Table: H39 W45 D35cm

x2


Product assembly

Anyday Wood 2 Seat Lounge Set

Step 5


Parts, fittings and tools

7 8 9 B C



Step 6 Final Assembly

Parts, fittings and tools



Internal dimensions

Stock Number: 82034211

Chair: H72 W60 D64cm

Table: H39 W45 D35cm

ANYDAY WOOD RANGE

Wood furniture

This product is made from FSC Acacia, this is a good material for outdoor furniture due to it being a hardwood with natural oils, this makes it durable and naturally weather-resistant in normal condition. The furniture has been painted and sealed with an acrylic paint, suitable for outdoor use.

The acrylic paint used is a premium wood polish that gives a high-quality finish to wooden surfaces. It also offers resistance against moisture dirt and grime.

Wood displays different grain patterns depending on which way they cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic to accelerate the aging process.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

Please make sure that all surfaces are protected from heat and liquids by mats and coasters. Wipe up any spills immediately and make sure that a mat or pad is placed under any paper if writing.

To extend the product life and appearance it is recommended to store the furniture in a cool dry, well ventilated place such as a garage or shed over winter or during periods of unseasonal weather.

Ensure that the furniture is clean and completely dry before putting in to storage. Do NOT enclose the product in a plastic or other non-permeable material as this promotes the growth of mildew and mould. Cover it with a dust sheet or furniture cover allowing the air to circulate around it.

Remove dust regularly with a clean soft brush and wipe down with a clean damp cloth. Bird droppings and tree sap should be cleaned off immediately.

The wood has been treated during manufacturing, so does not normally require an additional coating prior to use. If the furniture is intended to be left outside for a prolonged period of severe conditions, a coat of oil is required every 6 months depending on the environmental conditions to prolong the product lifespan.

Fine surface cracks can appear in hardwood over time. If the wood is regularly coated and the product is stored according to the guidance in this instruction manual, this should not affect the structural integrity of the product.

If your furniture comes with cushions, when not in use it is recommended that they are stored in a clean and dry environment. Wipe up any spills immediately and always refer to the care label which will either be sewn to the back of the cushion or sewn inside if your cushion has a zip closure.

How to care for your wood furniture

Place the product in a location with less direct sunlight, preferably under shade or parasol.

Regularly wipe and clean the furniture using a soft damp cloth.

Dilute dishwashing liquid in water to clean any stains and buff to dry.

The wood care maintenance guide is for reference only. It is recommended to follow the application guide provided by varnish/oil manufacturers. In order to maintain the appearance of the wood, regular coating of oil must be applied. The frequency will depend on the weather conditions experienced.

1. Oil is best applied with a clean cloth. Simply wipe the oil onto the wood surface straight from the container.
2. Treat all surfaces of the furniture. Please ensure that any hidden surfaces (such as those exposed when the furniture is turned upside down) are also treated. Particular care should be given to the end grain and any joints or crevices.
3. Let the surface dry out. This can take 4 to 12 hours but depends on the surrounding conditions.
4. Repeat step 2 & 3 with at least 2 more coats of oil. Extra coats will give semi gloss sheen once the oil has dried out. Any excess oil can be wiped off with a clean cloth. Please follow the application guide provided by varnish / oil manufacturers.

Safety instructions

This furniture has been designed for domestic use only.

Furniture can be dangerous if incorrectly installed or assembled, it should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving heavy objects to a new location they are completely disassembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.


Ensure that the furniture is always on a solid and level surface at all times.

With all articulated furniture, please exercise care when folding, unfolding and adjusting positions to avoid any possibility of pinched or trapped fingers.

Retain these instructions for future reference.

Warning:

- Never tilt the chair. Ensure the chair is always placed firmly on the ground.
- Regularly check leg attachment and retighten screws as necessary.
- Do not use chair if legs are unstable. Please check fixings and tighten as required.



Your feedback is very important to us and we would love to hear your comments on your new furniture. Please visit our website to leave a review. Thank you.