Product information

Aftercare and

Troubleshooting

- Indoor use only
- Dimmable When used with dimmable bulbs

You've switched on the light, but it's not working:

2. Turn off the light and check that the bulb is inserted correctly

1. Check your power supply is switched on

- Replacement bulbs should be the same type and rating, available from John Lewis Partners or other established brands
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish



NICOLAS 6 LIGHT CEILING PENDANT USER GUIDE



	3. Check the bulb is still in working order	
	If there are technical issues with this product that you can't solve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.	
Specification	Max power: 6 x 7W Recommended bulb: 7W LED B22 Golf bulb for maximum brightness. Lower wattages are also suitable. Rated input: 220 –240V, 50Hz Bulbs not included IP rating: 20 Weight: 3.65kg	
5-year guarantee	At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 5-year guarantee.	
Recycling	This symbol $\overline{\mathbb{A}}$ indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further	

John Lewis plc SW1V 2QQ johnlewis.com details contact your local council or visit www.recycle-more.co.uk.

Please retain these instructions for future reference.

03/10/2024

Made in China

Getting started	Thank you for purchasing this John Lewis & Partners product. For your safety, and to make sure everything is working properly, please read the instructions carefully before use.
Warnings	This is a Class 1 product and must be earthed. It is recommended that this fitting is installed by a qualified electrician. Install in accordance with the IEE Wiring regulations and the Building Regulations. To prevent electrocution switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge If you are in any doubt, please consult a qualified electrician. This light fitting should be connected to a 5 amp fused circuit. If replacing an existing fitting, make a note of the connections. Always use the correct type and wattage bulb. Never exceed the wattage stated. Dispose of used bulbs carefully. This product is suitable for installation on surfaces with normal flammability e.g. wood, plasterboard, masonry. It is not suitable for use on highly flammable surfaces (e.g. polystyrene, textiles). For your safety, always switch off the supply and allow the fitting to cool down before changing lightbulbs, fitting shades, cleaning or adjusting. Ensure lampholder parts are securely fastened together.

Parts list



Product assembly

Step 1

Carefully unpack the carton, making sure all the parts are present before assembly. Before removing the existing fitting, carefully note the position of each set of wires.

Step 2

Remove the fixing bracket (A) from the product by unscrewing the two side screws (B) and retain for reuse. Ensure there is a solid mounting surface to support the weight of the light fitting. Using the fixing bracket as a template, mark the position of the mounting holes. Drill holes and fit supplied wall plugs (C) (suitable for masonry only). Take care to avoid damaging any concealed wiring and pipes. Fix the bracket to the ceiling using supplied screws (D).

Please note: This is a heavy product and appropriate ceiling fittings MUST be used to support the weight.

Step 3

The hanging height of this product can be adjusted. Unscrew the carabiner (E) on the bottom chain link and refit to achieve the desired drop. Re-tighten to secure and then remove excess chain links with 2 pairs of pliers. Pull the cable through the cord grip (F) until the desired height is achieved. Always ensure the weight of the product is supported by the chain and not the cable.

Step 4

Having identified the household wiring from your existing light fitting, connect to the connection block (G) inside the product in the following way. Check that: You have correctly identified the house wires. The connections are tight. No loose strands have been left out of the connection block.



Step 5

To attach the shades (H), first remove the shade rings (I) from threaded lampholders. Place the shades over the lampholders and refit the shade rings. Tighten to secure. Take care not to loosen the lower lampholder ring.

Step 6

Fit the recommended bulbs (J).

Step 7

Re-attach the product to the fixing bracket using the two screws removed in step 2 and tighten to secure. Take care not to trap any wiring. Your light is now ready for use.

Please note: The position of the shades cannot be adjusted and thumb screws on the joints of the shades and arms are for decorative purposes only.







E