Product information

- Indoor use only
- 3 step dimmable
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish
- This product contains Li-ion batteries

Aftercare and **Troubleshooting**

Please note the touch sensor will use a small amount of current at all times and will slowly drain the battery even when the light is off.

If you find the lamp turning itself off, even when the product is put on charge, it means the battery has been almost completely drained and needs initial charging before the lamp can be switched on again. Please refer to Step 4.

If there are technical issues with this product that you are unable to resolve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.

Specification

Max power: 2 x 2W LED 2 × 3000K 129Lm

INPUT Max.: 5W DC 5V 1A Battery: 3.6V 3600mAh

IP rating: 20 Weight: 2kg

Charging time: 8 hours when fully discharged

4 hours (approx.) in normal use

Direct current



For further information please visit: www.lighting-info.co.uk/106266

2-year guarantee

At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 2-year guarantee.

Recycling

This symbol Indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

John Lewis plc SW1V 2QQ johnlewis.com




Please retain these instructions for future reference. Made in China





MINI LED MUSHROOM TABLE LAMP SET OF 2 **USFR GUIDF**





Getting started

Thank you for purchasing this John Lewis & Partners product. For your safety, and to make sure everything is working properly, please read the instructions carefully before use.

Warnings

This product is battery powered and the internal battery is recharged via a supplied USB-A to USB-C cable.

This product should only be connected to equipment of Class II or class III. Batteries are only to be charged by persons over 8 years of age.

Only charge via a input max. 5W DC 5V 1A SELV plug-in adapter (phone charger or similar USB outlet).

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

This product is for indoor use only, and not suitable for a bathroom or outdoor location.

Do not plug this product directly into the mains or by other means other than the supplied cable.

The transformer or power supply is not a toy.

This product is not suitable for children under 3 years of age.

The battery must not be opened, destroyed or incinerated.

The battery in this product is non-replaceable and if damage occurs must be disposed of responsibly.

Parts list

Description	Image	Quantity
Light fittings		x 2
Shades		x 2
USB cables		× 2

Product assembly

Step 1

Carefully unpack the carton, making sure all the parts are present before assembly.

Step 2

Attach the shades (A) by screwing onto the top of the lamps in a clockwise direction. Do not overtighten.

Step 3

Connect the USB cables to the products (B) and to a USB outlet (C) (phone charger or similar USB outlet rated input max. 5W DC 5V 1A).

Step 4

Charge the batterys, which are already fitted to the products before first use. Ensure the products are fully charged before operating. The light indicator (E) will turn from red to green when fully charged.

Your table lamps are now ready for use.

To operate the on/off dimmer, touch the buttons (D) on the back of your lamps. (one touch low light level, second touch brighter, third touch brightest and fourth to turn off).

When used on the brightest setting the lights will start to dim after 6-8 hours of use. Top up the battery by charging the lamps until the lights turn green (approx. 4 hours).

Always unplug after charging. Do not use while charging to extend battery life.

