




# COAST MIDDLE UNIT

## H60 W75 D75

### USER GUIDE



Product Code:  
82032203


Getting started

Thank you for purchasing the Coast middle unit. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product. At John Lewis, we are committed to making great products possible. From our in-house Design Team, to our Buyers, we work together to bring great design to life. Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell.

We are all committed to designing and developing products to the highest industry standards. We hope you are happy with your product and welcome any feedback or comments you may have.


John Lewis & Partners

Your middle unit



Ref	Description	Dimensions	Qty
A	Chair Frame	H46 W75 D75	1
B	Legs	H19 W45 D45	4
C	Seat cushion	H18 W70 D70	1
D	Back cushion	H20 W70 D43	1

Fixtures and fittings



Fixtures and fitting supplied (actual size)


Ref	Description	Qty	<div>mm0102030405060708090100110</div>
①	Bolt M6 x 55 (mm) with Nuts	8	

Fixtures and fitting supplied (not actual size)


Ref	Description	Dimensions	Qty	
②	Washer	6.5x20x2 mm	8	
③	Spring Washer	6.5x13x1.5 mm	8	
④	Allen Key	4 mm	1	

Step by step assembly  
instructions

Step 1.



Step 2.



## Important safety information

### Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

### Do's

- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Spare parts are available, please contact our Furniture Aftercare Team on 03456 049 049 if you need assistance
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

### Dont's

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.



---

## How to care for your wood furniture

Place the product in a location with less direct sunlight, preferably under shade or parasol.

Regularly wipe and clean the furniture using a soft damp cloth.

Dilute dishwashing liquid in water to clean any stains and buff to dry.

The wood care maintenance guide is for reference only. It is recommended to follow the application guide provided by varnish/oil manufacturers. In order to maintain the appearance of the wood, regular coating of oil must be applied. The frequency will depend on the weather conditions experienced.

1. Oil is best applied with a clean cloth. Simply wipe the oil onto the wood surface straight from the container.
2. Treat all surfaces of the furniture. Please ensure that any hidden surfaces (such as those exposed when the furniture is turned upside down) are also treated. Particular care should be given to the end grain and any joints or crevices.
3. Let the surface dry out. This can take 4 to 12 hours but depends on the surrounding conditions.
4. Repeat step 2 & 3 with at least 2 more coats of oil. Extra coats will give semi gloss sheen once the oil has dried out. Any excess oil can be wiped off with a clean cloth. Please follow the application guide provided by varnish / oil manufacturers.

---

## Safety instructions

This furniture has been designed for domestic use only.

Furniture can be dangerous if incorrectly installed or assembled, it should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving heavy objects to a new location they are completely disassembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Ensure that the furniture is always on a solid and level surface at all times.


With all articulated furniture, please exercise care when folding, unfolding and adjusting positions to avoid any possibility of pinched or trapped fingers.

Retain these instructions for future reference.

---

## Warning:

- Never tilt the chair. Ensure the chair is always placed firmly on the ground.
- Regularly check leg attachment and retighten screws as necessary .
- Do not use chair if legs are unstable. Please check fixings and tighten as required.



Your feedback is very important to us and we would love to hear your comments on your new furniture. Please visit our website to leave a review. Thank you.

