

ASSEMBLY AND CARE INSTRUCTIONS

Sanctuary 3.0m Deluxe Wood-Effect Cantilever Parasol



This is an important document.

Please retain for future reference.

Please keep your receipt of purchase. Please note we are unable to process any warranty claim without proof of purchase

Care Instructions

- Always close the parasol during high winds or storms to prevent damage to the structure and fabric. Ensure it is securely tied down when not in use.
- Avoid leaving the parasol open when not in use, especially in adverse weather, as this can cause undue stress on the frame and mechanism.
- Clean the fabric regularly with warm soapy water and a soft cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the fabric or the wood-efect finish.
- Store the parasol in a dry place when not in use for long periods, particularly during winter months. Consider using a protective cover to prevent dust buildup and exposure to UV rays.
- Avoid placing the parasol near open flames or sources of high heat, as this may damage the fabric and frame.
- Ensure the parasol is correctly positioned and securely mounted in its base to prevent tipping or damage.

Necessary Tools



You will find a pack within this box tied to a red ribbon which contains the fittings.

WARNING – the fittings pack contains **SMALL ITEMS** which are a potential choking hazard and should be kept away from children at all times.

Assembly Requirements

Number of people required to assemble	*
Approximate Assembly time	15 minutes


Read this leaflet in full before commencing assembly.


Part List Supplied


A	CROSS BASE 1	1	AA	SCREW M6X15	())))))))))	1
В	CROSS BASE 2	1	ВВ	SCREW M10X25		8
С	LEG TUBE	1	CC	WASHER		8
D	LEG SLEEVE	1	DD	ALLEN KEY S5		1
Е	ROTATION BASE	1	EE	ALLEN KEY S8		1
F	BASE COVER 1	1				
G	BASE COVER 2	1				
Н	PARASOL	1				
ı	CRANK	1				

PLEASE ENSURE ALL FIXINGS ARE LEFT LOOSE DURING ASSEMBLY BUT ARE SECURELY TIGHTENED UPON COMPLETION.

Assembly Instructions







General Warranty Conditions

The warranty applies to the original purchaser from the date of purchase and covers manufacturing faults and defects only. If an item should fail as a result of a manufacturing fault or defect under normal domestic use, the manufacturer at their discretion will repair, refinish or replace the failed item.

The manufacturer reserves the right to substitute failed items with a similar product should the model or colour no longer be available. Any replacement will be for the failed item only, not a complete set. The original warranty period is not extended in the event of a repair, refinish or replacements.

In the event of a failure, it is the customer's responsibility to return the item to the store of purchase along with a copy of the receipt. LG Outdoor will confirm that

This product comes with a Limited Warranty which covers the following:

- 1 Year Limited Warranty on the steel frame, excluding damage caused by corrosion, scratching, pitting, flaking, or oxidization.
- 1 Year Limited Warranty on the parasol ribs.
- 1 Year Limited Warranty on all other materials and moving parts.



Dewmead Farm
New Inn Road
Hinxworth
SG7 5HG
consumer@leisuregrow.com