

## Product information

- Indoor use only
- Non-dimmable
- Replacement bulbs should be the same type and rating, available from John Lewis Partners or other established brands
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish

## Aftercare and Troubleshooting

### You've switched on the light, but it's not working:

1. Check your power supply is switched on
2. Turn off the light and check that the bulb is inserted correctly
3. Check the bulb is still in working order

If there are technical issues with this product that you can't solve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.


## Specification

Max power: 1 x 10W  
Recommended bulb:  
10W LED E27 GLS bulb for maximum brightness.  
Lower wattages are also suitable.  
Rated input: 220 –240V, 50Hz  
Bulb not included  
IP rating: 20  
Weight: 8.0kg

## 5-year guarantee


At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 5-year guarantee.

## Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk).



# CONCERT FLOOR LAMP USER GUIDE



John Lewis plc  
SW1V 2QQ  
[johnlewis.com](http://johnlewis.com)

Made in China



09/09/2025

Please retain these instructions for future reference.



Product Code:  
12000203






## Getting started

Thank you for purchasing this John Lewis & Partners product. For your safety, and to make sure everything is working properly, please read the instructions carefully before use.

## Warnings

This is a Class II product and must NOT be earthed. It is for indoor use only, and not suitable for a bathroom location. Your lamp has been packaged as separate parts to prevent damage during transit. The lamp must be protected by a 3 amp fuse in the mains plug. Do not plug into the mains until your lamp is fully assembled. Under no circumstances must this floor lamp be covered with any material as this could pose a safety hazard. It must be used on a stable, flat surface. **When manoeuvring or assembling this product, it must be lifted by the base.** Always use correct type and wattage bulb. Never exceed the wattage stated. If the mains cable becomes damaged it must only be replaced by a technically competent, qualified person. For your safety, always switch off the supply before cleaning or changing the bulb.

## Parts list

Description	Image	Quantity
Light fitting (3 sections + base)		x 1
Shade ring (fitted to lampholder)		x 1
Shade		x 1
Gimbal		x 1
Finial (fitted to gimbal)		x 1

## Product assembly

### Step 1

Carefully unpack the carton, making sure all the parts are present before assembly and place on a stable, flat surface. Remove the protective plastic end-caps from the tubes (A).

### Step 2

Screw tube (C) onto the lampholder section (B) in a clockwise direction. Take care not to trap the cable or cross the threads. Then screw tube (D) onto tube (C) in the same way.

### Step 3

Gently pull any excess cable through the base (E) and then out through the side of the base. Turn the completed assembly anticlockwise approximately 6 times. (Turning the tubes anticlockwise first ensures that the cable will straighten when the tubes are fully assembled).

### Step 4

Screw the assembly in a clockwise direction on to the base.

### Step 5

Stand the product upright and check the tightness of the joints.

### Step 6

Remove the shade ring (G) from the lampholder. Place the gimbal (F) over the lampholder and secure in place by refitting the shade ring.

### Step 7

Fit the recommended bulb (H) as per the details overleaf.

### Step 8

Remove the finial (J) from the top of the gimbal and fit the shade (I). Refit the finial to secure the shade in place.

### Step 9

Unbundle the cable from the cable tie. Your floor lamp is now ready to use. Switch on using the floor switch.

