

Product information

- Indoor use only
- Dimmable - When used with dimmable bulbs
- Replacement bulbs should be the same type and rating, available from John Lewis Partners or other established brands
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish
- Glass parts - Use a dry or slightly damp cloth. Do not use abrasive materials as these will damage the finish. Take care when handling glass parts to avoid damage or injury

Aftercare and Troubleshooting

You've switched on the light, but it's not working:

1. Check your power supply is switched on
2. Turn off the light and check that the bulb is inserted correctly
3. Check the bulb is still in working order

If there are technical issues with this product that you can't solve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.

Specification

Max power: 2 x 6W
Recommended bulb:
6W LED E14 dimmable Golf bulb for maximum brightness.
Lower wattages are also suitable.
Rated input: 220 -240V, 50Hz
Bulbs not included
IP rating: 20
Weight: 2.00kg

5-year guarantee

At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 5-year guarantee.

Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

John Lewis plc
SW1V 2QQ
johnlewis.com

Made in China




30/03/2026

Please retain these instructions for future reference.



SEMLA TABLE LAMP USER GUIDE



Product Code:
70670601



Getting started

Thank you for purchasing this John Lewis & Partners product. For your safety, and to make sure everything is working properly, please read the instructions carefully before use.

Warnings

This is a Class II product and must NOT be earthed.
It is for indoor use only, and not suitable for a bathroom location.
Do not plug into the mains until your lamp is fully assembled. It must be used on a stable, flat surface.
Under no circumstances must this table lamp be covered with any material as this could pose a safety hazard.
When manoeuvring the lamp it must be lifted from the bottom section.
The lamp must be protected by a 3 Amp fuse in the mains plug.
If you are in any doubt, please consult a qualified electrician.
For your safety, always switch off the power supply before cleaning or changing the bulb.
Always use correct type and wattage bulb. Never exceed the wattage stated.
If the mains cable becomes damaged it must only be replaced by a technically competent, qualified person to avoid a hazard. Ensure cables do not present a trip hazard or strangulation hazard.
This product contains glass so care must be taken when fitting or handling to prevent personal injury or damage to the product.

Parts list

Description	Image	Quantity
Light fitting		x 1
Spacer		x 1
Metal washer		x 1
Rubber washer		x 1
Shade		x 1
Topper		x 1

Product assembly

Step 1

Carefully unpack the carton, making sure all the parts are present before assembly and place the lamp on a stable, flat surface.

Step 2

Undo the topper (F) and remove the spacer (A), metal washer (B) and rubber washer (C).

Step 3

Screw the spacer (A) in a clockwise direction onto the top of the product. Fit the metal washer (B), then rubber washer (C).

Step 4

Fit the recommended bulbs (D) as per the details overleaf. **Please note:** This product will only function correctly with dimmable bulbs.

Step 5

Place the hole in the glass shade (E) over the stem on the product and screw the topper (F) onto the top of the shade to secure in place. Tighten with light pressure.

Step 6

Your table lamp is now ready for use.

To operate the dimmer, touch the button on the base (G). (one touch low light level, second touch brighter, third touch brightest and fourth to turn off).

If your lamp will not illuminate, please check the bulb is a dimmable bulb, the 3 Amp fuse in the plug and ultimately check the relevant fuse in your fuse box. If unsuccessful please contact our customer service team.

