

For use

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.

Fitting/Replacing the bulb - Max 60W

During use the bulb and light fitting get very hot. Always switch off at the mains and allow the bulb to cool before replacing. Always use a replacement bulb of the same type and never exceed maximum wattage. Dispose of used bulbs carefully.

Specification


Maximum wattage: 1 x 60W

Voltage: 240V, 50Hz

IP Rating: 20

Weight: 0.8kg



This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis do not operate instore take back, but as members of the Distributor Trade Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.


We have taken great care to ensure that this product reaches you in perfect condition. However, should any parts be damaged or missing please contact our Product Helpline on (01202) 690945.

John Lewis Partnership
171 Victoria Street
London SW1E 5NN
johnlewis.com

Made in China

John Lewis

User Manual
Zia Pendant Shade



Warnings!

To prevent electrocution switch off at mains supply before installing or maintaining this fitting.

Ensure other persons cannot restore electricity supply without your knowledge. If you are in any doubt, please consult a qualified electrician.

Always use the correct type and wattage bulb. Never exceed the wattage stated.

When changing a bulb, always switch off at the mains and allow the bulb to cool down before handling. Dispose of used bulbs carefully.

This product is suitable for domestic indoor use only.

Clean only with a dry duster.

Assembly

Refer to assembly diagrams opposite. Carefully unpack the carton, making sure all the parts are present before assembly.

Step 1

Remove the outer shade ring (A) from the lampholder (B)

Step 2

Place the gimbal (C) over the lampholder (B). Remove the inner shade ring if you are using an E27 lampholder. Make sure the hooks are facing upwards. Secure the gimbal in place by refitting the outer shade ring (A).

Step 3

Fit the bulb. Please refer to the instructions below.

Step 4

Hook the loops of the shade (D) over the gimbal (C) to secure the shade in place.

