


Moritz Console Table



H74.8 W110 D38cm

Thank you for purchasing the Moritz Console Table. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

We are committed to making great products possible.


From our in-house Design Team, to our Buyers, we work together to bring great design to life.

Our expert Product Technologists work collaboratively with our buyers and suppliers to ensure the legality, safety and quality of the product we sell.

We are all committed to designing and developing products to the highest industry standards.

We hope you are happy with your product and welcome any feedback or comments you may have.


Tools required



Time to assemble

25 mins

People to assemble



Important safety information

Warnings






- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

Don'ts

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.




Your Table





Ref	Description	Dimensions	Qty
❶	Top	110cm x 38cm x 2cm	1
❷	Base unit	73m x 77m x 30cm	1




Fixtures and fittings



Fixtures and fittings
supplied (actual size)

Ref	Description	Dimensions	Qty	mm
A	Big screw	M5 x 20mm	4	
B	Grub screws	6x6mm	4	

Fixtures and fittings
supplied (not actual size)



Ref	Description	Dimensions	Qty	
C	Allen key	#2.5	1	
D	Allen key	#3	1	
E	Stainless steel grommet fitting	Dia.20 x 12mm	4	

Product assembly

Moritz Console Table

Step 1



Parts, fittings and tools



Please note, the base is very heavy and needs to be unpacked as near to its final location as possible. Very carefully remove the base and stem unit from the carton. There is an MDF packing board on top of the stem which needs to be removed (see Step Two). To avoid scratches and possible damage carry out all steps on a clean, soft surface such as a rug or large cloth. With 2 people, carefully tip the table to one side onto a soft surface. Use the allen (C) key to gently loosen each of the 8 screws by 1 turn only (turn in anticlockwise direction). This helps to prepare for fixing the glass top in Step Four.

Step 2

Parts, fittings and tools



To remove the top MDF packing board, hold the wing nuts and unscrew the allen bolts. Then lift off the MDF packing board from the top of the base.


Product assembly

Moritz Console Table

Step 3

Parts, fittings and tools

2 A D E




Position the stainless steel grommets (E) on top of the leg stems. Locate the M6 countersink allen head bolts (A) and very carefully (to avoid cross-threading) tighten the bolts using the allen key (D)

Step 4

Parts, fittings and tools

1 2



Whilst 1 person holds the glass top (1) the second person should align the grommets on top of the metal stems (2) with the bosses on the glass top. Carefully lower the glass into position and take care not to scratch the glass at this stage.


Product assembly

Moritz Console Table

Step 5

Parts, fittings and tools

1 2 B C




Carefully locate the M6 grub screws (B) as shown below. Tighten using the allen key (C) by turning clockwise. Ensure the leg is pushed hard up to the metal boss (on the glass) whilst tightening. Repeat for all 4 legs.

Step 6

Parts, fittings and tools


2 C



Using the allen key (C) firmly re-tighten each of the 8 screws on the base (turn in clockwise direction).

Step 7

Parts, fittings and tools



The table can be levelled using the adjustable feet on the underside of the table base.

Care guide

How to care for your glass and metal furniture

For glass elements use glass cleaner or soapy water for cleaning, do not use anything abrasive as this may damage the surface of the product. **Note: Glass can scratch in normal use therefore please protect surfaces from scratches and marks by using mats and coasters.**

Protect the metal elements from spillage, sunlight and heat. A slightly damp cloth is the best cleaning agent for the material. Dry and polish with a non abrasive soft cloth.

Do not use any abrasive cleaner or harsh detergent on the metal elements as this can damage the surface. Avoid spilling or dropping crumbs of food with a high fat content on the surface as this can permanently mark the metal.

Safety instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and retighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

Glass furniture warning

Do not place very hot or very cold items glass surface(s) unless adequately thick table mats are used to prevent such items from coming into contact with the glass.

Do not sit or stand upon glass surface(s)

Do not use the glass as a chopping surface. Do not strike the glass with hard or pointed items.

Tempered glass is designed to break into very small fragments for customer safety. On very rare occasions including when not in direct use, glass can break for the following reasons: -Surface damage and scratches (protect the surface with mats during use). Please take extra care to ensure no heavy or sharp objects impact this product. -Extremes of temperature. Avoid areas where the item can become very hot and cold.

Retain these instructions for future reference.

Your feedback is very important to us and we would love to hear your comments on your new furniture. Please visit our website to leave a review. Thank you.

John Lewis Partnership
171 Victoria Street
London SW1E 5NN
johnlewis.com