

Dante 150cm 6 Seat Table

Stock number: 820/82008, 820/82021

Thank you for purchasing your **Dante 150cm 6 Seat Table**. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Pre-assembly preparation

Please ensure instructions are read in full before using this product.

Necessary Tools



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.





This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.


This product takes approximately **20 MINUTES** to assemble with **2 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.

Fittings and parts checklist

Parts List					
Part No.	Diagram	Qty	Part No.	Diagram	Qty
A		1 PC	B		1 PC
C		4 PCS	D	 M6*20mm	4 PCS
E		4 PCS	F		1 PC
G		4 PCS	H		1 PC



Step by step assembly instructions

Step One

Place the table base (B) on a clean, level area.

Step Two

With the help of another person, place the table top (A) on top of the table base (B), aligning all holes in each part.


Loosely attach the top to the base using washers (E) and bolts (D).

Only tighten the bolts when all four sets of bolts and washers are in place and turn freely. Once you are satisfied with the alignment of the components carefully tighten the bolts using spanner (H). Do not over-tighten.

Cover all bolts with plastic caps (C).

Step Three

There are adjustable feet (G) at the bottom of each leg, enabling the table to be levelled to its surrounding if necessary.



Step Four

With the help of another person, lift the glass top (F) carefully into place, taking care not to damage the rattan or to trap or pinch your fingers.

Your table is now ready for use.

Care and Maintenance

To ensure the maximum life from your garden furniture, we recommend storing in a dry, well-ventilated space such as a garage or wooden shed over winter.

To clean the table, simply wipe down by hand with a damp sponge and a weak solution of soap and water. Do not use abrasive cleaners, as these will damage the synthetic wicker.

Safety Instructions

If the glass is chipped or broken, stop using the table and consult the manufacturer or supplier.

WARNING:

Do not place very hot or very cold items on the glass surface unless adequately thick table-mats are used to prevent such items from coming into contact with the glass.

Do not stand or sit on the table.

Do not use the glass as a chopping surface. Do not strike glass with hard or pointed items.

When cleaning glass panel, use a damp cloth or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substances containing abrasives since these substances scratch glass.

Never drag furniture when moving it, always lift it.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly used. No liability will be accepted for damage or injury caused by incorrect use of this product.

Ensure the table is always placed on level ground.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE