

Product information

- Indoor use only
- Dimmable
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish
- Do not use this product if the glass cover is cracked or damaged

Aftercare and Troubleshooting


If there are technical issues with this product that you can't solve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.

Specification

Max power: 24.12W
Rated input: 220 –240V, 50Hz
IP rating: 20
Weight: 5.6kg
Lumen output: 2060
Colour temperature: Warm white (3000K)
This product contains a light source of energy efficiency class G
For further information please visit: www.lighting-info.co.uk/58577



Non-replaceable light source




Replaceable control gear by a professional

5-year guarantee

At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 5-year guarantee.

Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

John Lewis plc
SW1V 2QQ
johnlewis.com

Made in China




25/04/2024

Please retain these instructions for future reference.



LEVITY FLOOR LIGHT USER GUIDE



Product Code:
12010106
12010108

Thank you for purchasing this Levity floor light. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.

Warnings!










For your safety, always switch off the supply before cleaning or removing shades.

Your standard lamp has been packaged as five separate parts to prevent damage during transit.

When manoeuvring or assembling this product, it must be lifted from the bottom.

The external flexible cable of the luminaire cannot be replaced: if the cord is damaged the luminaire shall be destroyed.

Parts List

Plug		1	Allen screws		2
Shade		1	Central tubes		4
Spanner		1	Central panel		1
Allen key		1			
Fixing kit		2	Base		1

Assembly

Refer to assembly drawing opposite. Carefully unpack the carton, making sure all the parts are present before assembly.

Step 1

Do not attempt to plug in or use this product until it has been fully assembled. Disconnect from mains during assembly or maintenance.

Step 2

Remove all packaging from the base, the central tubes and shade. Remove any cable protection pieces in the ends of the tubes.

Step 3

Locate tubes A and B into the sockets on the shade. Secure the shade in place by tightening the screws using the supplied hex key. Do not overtighten.

Step 4

Screw Tubes C and D on to the central panel in a clockwise direction. Take care not to trap the cable or cross the thread.

Step 5

Locate the end of Tubes C and D on to the base. Gently pull any excess cable through from Tube D under the base. Fit the washers and nuts onto the threads and securely tighten using the supplied spanner.

Step 6

Stand the product upright and check the tightness of the joints.

Step 7

Your standard lamp is now ready to use. Attach the power cable to the plug and plug in to the mains supply. Switch on with the switch on the central panel.

