


Mendel Media Unit

Stock Number: 862 39201
862 39203



L150 W38 H50cm

1

Thank you for purchasing the Mendel Media Unit. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

At John Lewis, we are committed to making great products possible.

From our in-house Design Team, to our Buyers, we work together to bring great design to life.

Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell.


We are all committed to designing and developing products to the highest industry standards.

We hope you are happy with your product and welcome any feedback or comments you may have.

The John Lewis Team

Time to assemble 10 Minutes

People to assemble



The diagram shows two simple line-art icons of human figures standing side-by-side. Each figure has a circular head, a rectangular torso, and two vertical lines for legs. This visual representation indicates that two people are required for the assembly process.

Important safety information

Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

Do's

- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with ground at all times.


Don'ts

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.



Mendel Sideboard

Stock Number: 862 39201 / 862 39203




Ref	Description	Dimensions	Qty.
1	Top	150x38cm	1
2	Leg	124x33cm	1

Dimension : L150 W38 H50cm


Mendel Media Unit

Stock Number: 862 39201 / 862 39203

Fixtures and Fittings Supplied



Fixtures and Fittings Supplied (Actual Size)


Ref	Description	Dimensions	Qty.	
A	Shelf Pin	5x16mm	4	

Assembly:- Mendel Media Unit

Stock Number: 862 39201 / 862 39203

Step 1


Parts, fittings & tools



Step 2

Parts, fittings & tools

A




Mendel Media Unit

Stock Number: 862 39201 / 862 39203


Step 3

Parts, fittings & tools



Step 4

Parts, fittings & tools




Mendel Media Unit

Stock Number: 862 39201 / 862 39203

Step 5


Parts, fittings & tools



Hinge Adjustment Instructions


1- Sideways Adjustments.-

This adjustment system allows the door to be moved sideways without changing the gap behind the door. Adjust the screw (A) in or out until the door is aligned to satisfaction:




2- Height Adjustment -

Partially unscrew (B) which will allow you to adjust the height of the door. Once in place, retighten screw (B). Optionally, the adjustment cam (C) on the mounting plate can be used for aligning the door height.




3- Depth Adjustment -

Adjust the distance between the door and the side of the cabinet by turning the adjustment cam (D). Turn counter clockwise to increase the distance and clockwise to decrease the distance.



Ready to Use



Care guide

Care and maintenance

Wood furniture

Wood displays different grain patterns depending on which way it is cut – for example, the ‘medullary ray’ which can appear on oak furniture is a mark of good quality timber – these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allows a distinctive pattern to be created on some surfaces, such as tabletops and drawer fronts by the way slivers are arranged.

All timber and veneer surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Spray polishes are best avoided as they contain silicones which may spoil the furniture’s surface when building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home, but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by home heating can cause damage such as warping.

Safety instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and retighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person.

No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Do not place weight too close edge of the table and do not lean on it .

Retain these instructions for future reference.

Your feedback is very important to us and we would love to hear your comments on your new furniture.

Please visit our website to leave a review. Thank you.

John Lewis Partnership

171 Victoria Street

London SVV1E 5NN

www.johnlewis.com

