

John Lewis Partnership 171 Victoria Street London SW1E 5NN johnlewis.com UK X

Made in China

Please retain this information for future reference


Lights and sound vehicles

Getting started


Thank you for purchasing this John Lewis toy. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Light and sound vehicles

Changing the batteries Batteries not included







- 1,5VR6 -2 x 1,5V R6 (AA)



Batteries should be removed and replaced by adults only.

Only use recommended batteries or those of the same or equivalent type.

Do not mix old and new batteries or batteries of different types.

Batteries are to be inserted with the correct polarity.

The supply terminals are not to be short-circuited.

Remove exhausted batteries from item.

Remove batteries if equipment is not used for extended periods of time.

Rechargeable batteries are to be removed from the item before being recharged.

Rechargeable batteries are only to be charged under adult supervision.

Do not attempt to recharge non-rechargeable batteries.

Batteries contain substances that may be harmful to the environment and human health.

Keep out of the reach of children and seek immediate medical help if swallowed. After replacing batteries please ensure that the battery compartment is securely screwed back into position.

Warning!



Not suitable for children under 3 years.

Small parts - Choking Hazard.

Long Cord – Strangulation hazard.

Remove all packaging/tags before giving item to a child.

Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. This toy produces flashes that may trigger epilepsy in sensitised individuals.

Recycling and disposal



This symbol indicates that batteries should not be disposed of in the normal household waste but taken to appropriate local recycling for the contract of the household waste but taken to appropriate local recycling facilities, where and when these are available. Never throw batteries in a fire or attempt to open outer casing.

This product should not be treated as normal household waste and it should be recycled. John Lewis do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.