



John Lewis Partnership
171 Victoria Street
London SW1E 5NN
johnlewis.com



Please retain these instructions for future reference

Made in China

Spy mission kit

Battery safety

Batteries should be removed and replaced by adults only.

Only use recommended batteries or those of the same or equivalent type.
Do not mix old and new batteries or batteries of different types.
Batteries are to be inserted with the correct polarity.
The supply terminals are not to be short-circuited.
Remove exhausted batteries from item.
Remove batteries if equipment is not used for extended periods of time.
Rechargeable batteries are to be removed from the item before being recharged.
Rechargeable batteries are only to be charged under adult supervision.
Do not attempt to recharge non-rechargeable batteries.
Batteries contain substances that may be harmful to the environment and human health.
Keep out of the reach of children and seek immediate medical help if swallowed.

Warning!

Not suitable for children under 3 years.
Small parts - Choking hazard.
Use with care and only under adult supervision.
Recommended for children 8+.

Remove all packaging / tags before giving to a child.

Recycling and disposal



This symbol indicates that batteries should not be disposed of in the normal household waste but taken to appropriate local recycling facilities, where and when these are available. Never throw batteries in a fire or attempt to open outer casing.


The symbol indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

Thank you for purchasing this toy.

Please read the instructions and warnings carefully before use.

Parts list


1. Earphone	8. Flashlight
2. Secret paper safe	9. Objective lens holder
3. Storage compartment	10. MicroSD card holder
4. Eyepiece with compass	11. Listener On/Off switch/Volume Control
5. Objective lens / Magnifier	12. Flashlight switch
6. Focus knob	13. Eyepiece holder
7. Receiver	



Instructions for use


Secret Paper Safe

Roll the paper note to fit inside the shorter part and close the safe as shown.




MicroSD Card Holder

Only insert the MicroSD memory card with the proper orientation into the holder as shown.



Arm Protector

Adjust the two elastic arm bands and wear the device on your forearm as shown.




Flashlight

Flashlight hides inside the listener to help you work in the dark. Switch it on if needed.

Telescope


Install the eyepiece and the objective lens on the corresponding holder as shown. Align the lenses and look through the eyepiece. Adjust the position of the objective lens by turning the focus knob until the image is clear.

In case of any difficulty in adapting your viewing position when it is strapped to the arm, use it as a hand-held telescope.




Listener

1. Wear the device on your arm. You may hide it inside your sleeve. Unwind the receiver dish by turning the wheel clockwise and wear it on your palm as shown. Switch on the listener and adjust the volume. You may press it on the door or wall surface to hear the conversations on the other side.



2. Retract the receiver wire by turning the wheel anti-clockwise as shown. Store the receiver back into the case after use.



Changing the batteries

Your product is supplied with batteries. The Spy mission kit requires 3 x 1.5V AG13 (LR44) batteries (included).

1. With a small cross head screwdriver, loosen the screw from the battery door.
2. Remove the battery door.
3. Discard the old batteries.
4. Insert 3 x 1.5 Volt AG13 (LR44) batteries per the polarity markings in the battery compartment of each unit.
5. Replace the battery door and the screw.

