
Caring for your product

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.


Replace bulbs from John Lewis or established brand of the same type and compatibility.

Aftercare and Troubleshooting

Please ensure all screws and small pieces are properly tightened to the product.

When changing a bulb, always switch off the mains and allow the bulb to cool down before handling.

A bulb's watt rating indicates how much energy it uses. The higher the watt, the more energy it requires. Lumens is a measure of brightness. The higher the number of lumens, the brighter the light.



Specification

Max. power: 60W
Voltage: 220–240V~50Hz
IP rating: 20
Weight: 11.20 kg



5 year guarantee

At John Lewis & Partners we test every light to high quality standards so we are able to offer you a 5 year guarantee.

Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.



John Lewis Partnership
171 Victoria Street
London SW1E 5NN
johnlewis.com


Made in China

Please retain these instructions for future reference.



FISHING ROD FLOOR LAMP

USER GUIDE



Thank you for purchasing this Fishing Rod Floor Lamp.
Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.

Warnings



This lamp is for indoor use only.

This product is Class II.

The supply cord cannot be replaced. If the cord is damaged, the floor lamp should be destroyed in order to avoid a safety hazard.

Always use the correct type and rated power bulb. Never exceed the rated power stated.

Dispose of used bulbs carefully.


Parts list

Description	Image	Quantity
A Pole		1 PC
B Pole + Wire		1 PC
C Wood pole		1 PC
D Wood pole		1 PC
E Wood pole		1 PC
F Washer		1 PC
G Base		1 PC
H Washer		1 PC
I Nut		1 PC
J Wrench		1 PC
K Shade		1 PC
L Socket ring		1 PC

Recommended bulb


1 × 10 watt E27 LED bulb
 Bulbs replaceable
 Bulbs not included

Product assembly




1. Carefully unpack the carton, making sure all parts are included before assembly. Place lamp parts on a flat surface.


2. Screw pole (C) clockwise into pole (D) until tight.




3. Screw pole (D) clockwise into pole (E) until tight.



4. Insert pole (B) through the hole of pole (C) and then screw pole (A) clockwise into pole (B) until tight.




5. Remove the cord protector and throw it away before assembling lamp base (G).




6. Insert tube (E) through washer (F), base (G), & washer (H). Then, secure it by tightening nut (I) using wrench (J).

Note: The Arc lamp should face forward with the arms reaching over the base (see diagram below).



7. Socket ring (L) comes pre-assembled to the socket. In order to attach shade (K), unscrew socket ring (L). Then, place shade (K) onto the socket and screw back on socket ring (L) to secure shade (K).



Note: The arm of this lamp is adjustable forward and backward. In order to move the arm, slightly lift the front of the arm to relieve tension, and hold onto the wood pole steady with your other hand.

