

Product information

- Indoor use only
- Dimmable
- Replacement bulbs should be the same type and rating, available from John Lewis Partners or other established brands
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish
- Glass parts - Remove and use a damp cloth. Do not use abrasive materials as these will damage the finish. Take care when handling glass parts to avoid damage or injury

Aftercare and Troubleshooting

You've switched on the light, but it's not working:

1. Check your power supply is switched on
2. Turn off the light and check that the bulb is inserted correctly
3. Check the bulb is still in working order

If there are technical issues with this product that you can't solve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.


Specification

Max power: 40W
Recommended bulb:
1 x 6W E27 GLS LED bulb, or
1 x 28W E27 GLS Eco Halogen bulb
Rated input: 220 –240V, 50Hz
Bulbs not included
IP rating: 20
Weight: 3.43kg

5-year guarantee

At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 5-year guarantee.

Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

John Lewis Plc
171 Victoria Street
London SW1E 5NN
johnlewis.com

Made in China




01/11/2022

Please retain these instructions for future reference.



VICTORIA PENDANT USER GUIDE



Product Code:
70164401
70164402






Getting started

Thank you for purchasing this John Lewis & Partners product. For your safety, and to make sure everything is working properly, please read the instructions carefully before use.

Warnings

This is a Class 1 product and must be earthed. It is recommended that this fitting is installed by a qualified electrician. Install in accordance with the IEE Wiring regulations and the Building Regulations. To prevent electrocution switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge. If you are in any doubt, please consult a qualified electrician. This light fitting should be connected to a 5 amp fused circuit. If replacing an existing fitting, make a note of the connections. Always use the correct type and wattage bulb. Never exceed the wattage stated. When changing a bulb always switch off at the mains and allow to cool down. Dispose of used bulbs carefully. This product is suitable for indoor use only. This product is suitable for installation on surfaces with normal flammability e.g. wood, plasterboard, masonry. It is not suitable for use on highly flammable surfaces (e.g. polystyrene, textiles). For your safety, always switch off the supply before changing lightbulbs or cleaning.


Parts list

Description	Image	Quantity
Light fitting		x 1
Glass droplets		x 156
Spare glass droplets		x 2
Wall plugs		x 2
Screws		x 2

Product assembly

Step 1

Refer to assembly diagrams right. Carefully unpack the carton, making sure all the parts are present before assembly. Before removing the existing fitting, carefully note the position of each set of wires.




Step 2

Remove the fixing bracket (A) from the ceiling cover by the removing side screws (B) and washers (C). Attach to the ceiling using the screws provided. Ensure there is a joist at the point of fixing to support the weight of the product. Take care to avoid damaging any concealed wiring and pipes.


Step 3

The hanging height of this product can be adjusted. Work out the required height and remove chain links with 2 pairs of pliers. Pull the cable through the cord grip (D) until the desired height is achieved. Ensure the weight of the fitting is supported on the chain and not the cable.




Step 4

Having identified the household wiring from your existing light fitting, connect to the connection block inside the product in the following way. Check that: You have correctly identified the house wires. The connections are tight. No loose strands have been left out of the connection block.



Step 5

Re-attach the product to the fixing bracket and tighten the side screws. This product has "L" shaped fixing holes to allow easy fixing to the fixing bracket. Locate the "L" slots around the side screws (B) on fixing bracket (A). Rotate the ceiling cover to attach the product to the bracket. Tighten the screws to secure. Take care not to trap any wiring.



Step 6: Fitting the glass droplets

2 spare droplets are supplied should any need replacing. To fit a new droplet (E), simply feed the wire hook at the top of the droplet through the hole in the end of the scroll.

Fit the bulb (F). Replace fuse or circuit breaker and switch on. Your light is now ready for use.