





Step 1 Insert dowels **D** to back panel **A**.



Step 2 Insert shelf **B** on the dowels **D** then screw in screws **C** through back panel **A**.



Step 3 Place template **E** on the wall. Please use a spirit level to ensure that the template is straight. Drill the required holes in the wall using the template **E** and follow the guidance under fixings section.



Care instructions

Maximum load of 2.5kgs. Do not place heavy items on the shelf.
Wipe clean with a soft dry cloth.


Warnings!

The fitting pack contains small parts, which present a choking hazard. Keep fittings away from young children.

Product Code:

39370606
39370607

Pre-assembly preparation



Phillips head screwdriver and spirit level required

Thank you for purchasing this product. Please read the instructions and check pack contents carefully before starting assembly of this product. A full checklist of components is given in this leaflet. If any components are missing please contact John Lewis and partners customer services.

This product will take 1 person approximately 10 minutes to assemble.

The fitting pack contains small items which could present a choking hazard and should be KEPT AWAY FROM YOUNG CHILDREN.

Read this leaflet in full before commencing assembly.

Fittings and parts checklist

No.	Picture	Name	Qty	No.	Picture	Name	Qty
A		Back Panel	1	B		Shlef	1
C		Screw	4	D		Dowel	2
E		Template	1				

Helpful advice before you begin

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
3. Assemble this product on a soft surface.
4. We recommend a periodic check on all fixing points to make sure they remain fully tightened.
5. Keep out of reach of small children. It contains small parts which might present a choking hazard.
6. Do not use any other tools other than those recommended to build this product.

GUIDE TO WALL MOUNTING & FIXINGS

KEY INFORMATION




Warning: Wall fixing screws are not included since different wall materials require different types of screws / fixings. Please ensure you use the correct screws / fixings for your type of walls and seek professional advise if you are not sure. Failure of the product due to incorrect fixings is the responsibility of the installer.

Important - When drilling into the walls always check that there are no hidden wires or pipes etc.

Take care when drilling on glazed tile surfaces in case the drill slips.


FIXINGS

You can use one of the following types of wall plug if your walls are made of brick, breezeblock, concrete, stone or wood.




General Purpose wall plug

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general – purpose wall plugs can be used.




Plasterboard wall plug

For use when attaching light loads on to plasterboard partitions.




Cavity Fixing wall plug

For use with plasterboard partitions or hollow wooden doors.




Cavity Fixing – Heavy Duty wall plug

For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.



Hammer Fixing wall plug

For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



Shield Anchor wall plug – Heavy loads

For use with heavier loads such as TV and Hi-Fi speakers and satellite dishes etc.