


# Platform dining set-corner sofa

Stock number: 82006906



H70.5 W201 D78cm

Thank you for purchasing the Platform dining set-corner sofa. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.  
At John Lewis, we are committed to making great products possible.  
From our outdoor furniture Design Team, to our Buyers, we work together to bring great design to life.  
Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell.  
We are all committed to designing and developing products to the highest industry standards.  
We hope you are happy with your product and welcome any feedback or comments you may have.


The John Lewis Team

## Tools required



**Time to assemble**  
15 Mins

**People to assemble**



# Important safety information

## Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

## Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

## Don'ts

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.



# Your sofa




Ref	Description	Dimensions	Qty
①	Seat frame	1956x734mm	1
②	Back frame	2017x400mm	1
③	Back frame	770x400mm	1
④	Leg frame	275x25mm	2
⑤	Back cushion	2020x350mm	1
⑥	Back cushion	630x350mm	1
⑦	Seat cushion	1950x710mm	1

## Internal dimensions


Stock number: 82006906

Bench overall size: H70.5 W201 D78cm

# Fixtures and fittings



Fixtures and fittings  
supplied (actual size)

Ref	Description	Dimensions	Qty	mm
<b>A</b>	Screw	6mmx18mm	12	
<b>B</b>	Screw	6mmx40mm	1	

Fixtures and fittings  
supplied (not actual size)

Ref	Description	Dimensions	Qty	
<b>C</b>	Washer	12x1.1mm	13	
<b>D</b>	Cap	D14x6mm	13	
<b>E</b>	Allen Key		1	
<b>F</b>	Plastic clip		2	


# Product assembly

Platform dining set-corner sofa  
82006906

## Step 1

Parts, fittings and tools


A C D E I 5



## Step 2

Parts, fittings and tools

A C D E I 2




# Product assembly

Platform dining set-corner sofa  
82006906

## Step 3

Parts, fittings and tools


A C D E 3



## Step 4

Parts, fittings and tools

B C D E




# Product assembly

Platform dining set-corner sofa  
82006906

## Step 5

Parts, fittings and tools

5 6 7




Place the cushions into the frame, the sofa now is ready for use.

# User guide

Platform dining set-corer sofa  
82006906

Plastic clips are provided for connecting sofa frames.



## Care guide

### Care and Maintenance

Do not use a wire brush when removing dirt from this item as it may damage the paint leaving the surface open to corrosion.

To extend the product life and appearance it is advisable to store the furniture in a cool dry place over winter. Ensure that the furniture is clean and completely dry before putting in to storage. Do NOT enclose the product in a plastic or other non-permeable material as this creates moisture.

### Safety Instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

This furniture has been designed for domestic use only.

Do not use the chair as a ladder.


Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person.

No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Never tilt the chair. Ensure the chair is always placed firmly on the ground.

Regularly check leg attachment and retighten screws as necessary.

Do not use chair if legs are unstable. Please check fixings and tighten as required.



PLEASE RETAIN THIS INFORMATION LEAFLET FOR FUTURE REFERENCE