Care Instructions

- This tabletop is made from 100% recyclable PE Weave. Due to the nature of this material
 it may sag under direct sunlight but will return to its normal state upon cooling. To help
 reduce this occurrence we recommend using a parasol where possible
- Always ensure the Parasol Insert is in place before installing a Parasol
- When using a Parasol with this table, ensure a suitably weighted Parasol Base is used and never leave the Parasol up while unattended
- Please keep both glass and weave away from sources of extreme heat and naked flames
- Do not sit or stand on this table
- If removing the glass to clean, we recommend that two people lift the glass and place it on a soft, flat surface
- We recommend cleaning this product periodically with warm, soapy water and a cloth or non-abrasive brush. Do not use harsh or abrasive chemicals
- To keep your product looking its best, we would always recommend covering with an LG Outdoor Furniture Cover when not being used for longer periods.
- Throughout the winter months either bring indoors or cover as above. Failure to do so may invalidate your warranty

Necessary Tools (Supplied)



You will find a pack within this box tied to a red ribbon which contains the fittings.

WARNING – the fittings pack contains **SMALL ITEMS** which are a potential choking hazard and should be kept away from children at all times.

Assembly Requirements


Number of people required to assemble	* *	
Approximate Assembly time	20 minutes	

Read this leaflet in full before commencing assembly.

Part List Supplied

A	TABLE TOP		1	В	TABLE BASE(1)		2	С	TABLE BASE(2)		2
D	BOLT(M6X30L)		8	E	BOLT(M6X20L)		4	F	NUT(M6)		8
G	METAL WASHER (Φ6.5)	0	20	Н	PLASTIC NUT CAP(M6)	(D)	8	I	PLASTIC BOLT CAP(M6)	0	12
J	GLASS TOP	0	1	K	SHELF		1	L	ALLEN WRENCH		1
M	HEX WRENCH	5	1	N	PARASOL INSERT	OUTDOOR)	1	0	WEAVE ADJUSTER		1

Assembly Instructions



PLEASE ENSURE ALL FIXINGS ARE LEFT LOOSE DURING ASSEMBLY BUT ARE SECURELY TIGHTENED UPON COMPLETION.

Page 2 of 4 Page 3 of 4

General Warranty Conditions

The warranty applies to the original purchaser from the date of purchase and covers manufacturing faults and defects only. If an item should fail as a result of a manufacturing fault or defect under normal domestic use, the manufacturer at their discretion will repair, refinish or replace the failed item.

The manufacturer reserves the right to substitute failed items with a similar product should the model or colour no longer be available. Any replacement will be for the failed item only, not a complete set. The original warranty period is not extended in the event of a repair, refinish or replacements.

In the event of a failure, it is the customer's responsibility to return the item to the store of purchase along with a copy of the receipt. LG Outdoor will confirm that the customer has registered their warranty. Warranty specifically excludes general wear and tear, rusting of steel components and parts, corrosion, commercial use and damage caused as a result of failure to observe reasonable care, maintenance and assembly instructions for both furniture and hardware.

This product comes with a Limited Warranty which covers the following:

- * 3 Year Limited Warranty Aluminium Frames which excludes damage to the finish caused by corrosion, scratching, pitting, fading or oxidisation
- * 3 Year Limited Warranty Weave which excludes scratching of wicker finish and dis-colouration

For all other components not covered by the above a standard 12-month warranty will apply

To register your warranty please visit Igoutdoor.co.uk/furniture-warranty within 28 days of purchase



Dewmead Farm
New Inn Road
Hinxworth
SG7 5HG
consumer@leisuregrow.com



ASSEMBLY AND CARE INSTRUCTIONS

140x80cm Casual Dining Table



This is an important document.

Please retain for future reference.

Please keep your receipt of purchase. Please note we are unable to process any warranty claim without proof of purchase.

QSF LGLO201 - STSA140CT, STST140CT

Care Instructions

- This product is made from 100% recyclable PE Weave. Due to the nature of this material
 it may sag under direct sunlight but will return to its normal state upon cooling. To help
 reduce this occurrence we recommend using a parasol where possible
- Please keep sofa and cushions away from sources of extreme heat and naked flames
- Do not stand on this product
- Do not lean back on this product. This product is only designed to be used with all four feet touching the ground
- We recommend cleaning this product periodically with warm, soapy water and a cloth or non-abrasive brush. Do not use harsh or abrasive chemicals
- STAINSAFE Cushions should be cleaned with water only as detergents can weaken the stain-resistant coating. If detergents are used please retreat the affected area with a fabric protection spray.
- To keep your product looking its best, we would always recommend covering with an LG Outdoor Furniture Cover when not being used for longer periods. Throughout the winter months either bring indoors or cover as above. Failure to do so may invalidate your warranty

Necessary Tools

No tools required

You will find a pack within this box tied to a red ribbon which contains the fittings.

WARNING – the fittings pack contains **SMALL ITEMS** which are a potential choking hazard and should be kept away from children at all times.

Assembly Requirements


Number of people required to assemble	* *		
Approximate Assembly time	2 minutes		

Read this leaflet in full before commencing assembly.

Part List Supplied

A	RIGHT SOFA	1	В	CORNER SOFA	1
С	LEFT SOFA	1	D	MIDDLE SOFA	1
E	"U" CLIP	6			

Assembly Instructions



Page 2 of 4

General Warranty Conditions

The warranty applies to the original purchaser from the date of purchase and covers manufacturing faults and defects only. If an item should fail as a result of a manufacturing fault or defect under normal domestic use, the manufacturer at their discretion will repair, refinish or replace the failed item.

The manufacturer reserves the right to substitute failed items with a similar product should the model or colour no longer be available. Any replacement will be for the failed item only, not a complete set. The original warranty period is not extended in the event of a repair, refinish or replacements.

In the event of a failure, it is the customer's responsibility to return the item to the store of purchase along with a copy of the receipt. LG Outdoor will confirm that the customer has registered their warranty. Warranty specifically excludes general wear and tear, rusting of steel components and parts, corrosion, commercial use and damage caused as a result of failure to observe reasonable care, maintenance and assembly instructions for both furniture and hardware.

This product comes with a Limited Warranty which covers the following:

- * 3 Year Limited Warranty Aluminium Frames which excludes damage to the finish caused by corrosion, scratching, pitting, fading or oxidisation
- * 3 Year Limited Warranty Weave which excludes scratching of wicker finish and dis-colouration

For all other components not covered by the above a standard 12-month warranty will apply

To register your warranty please visit Igoutdoor.co.uk/furniture-warranty within 28 days of purchase



Dewmead Farm
New Inn Road
Hinxworth
SG7 5HG
consumer@leisuregrow.com



ASSEMBLY AND CARE INSTRUCTIONS

Rectangular Dining Modular Set Reclining Corner Sofa



This is an important document.

Please retain for future reference.

Please keep your receipt of purchase. Please note we are unable to process any warranty claim without proof of purchase.

QSF LGLO198 - STSA14BDL, STST14BDL, CRSC14BDL

Page 4 of 4 Page 1 of 4