


KETTLER

3.5 m & 3.0m Premium Free Arm Parasol

PL35 & PLS30



IMPORTANT

PLEASE KEEP THIS BOOKLET FOR FUTURE REFERENCE.
THIS IS IMPORTANT INFORMATION REGARDING THE
USE AND CARE OF YOUR GARDEN FURNITURE.




















ASSEMBLY
TIME



PERSONS
REQUIRED

Parts List

<p>(A) Parasol</p>  <p>x1</p>	<p>(B) Solar Panel</p>  <p>x1</p>	<p>(C) Protective Cover Including 3-Part Support Rod</p>  <p>x1</p>	
<p>(D) Base Lever</p>  <p>x1</p>	<p>(I) Allen Key & Spanner</p>  <p>x1 x1</p>	<p>(F) Adjusting Lever</p>  <p>x1</p>	
<p>(P) USB Cable</p>  <p>x1</p>	<p>(Q) Wireless Speaker</p>  <p>x1</p>	<p>(R) Bolt with washer M10x20mm</p>  <p>x4</p> <p>(S) Removable Battery Pack</p>  <p>x1</p>	
<p>(J) Inverted Base Stem</p>  <p>x1</p>	<p>(K) Base Shell</p>  <p>x1</p>	<p>(L) Base Lid</p>  <p>x1</p>	<p>(M) Inverted Base Stem</p>  <p>x1</p>
<p>(H) Plate Bolts M8x23</p>  <p>x4</p>	<p>(N) Allen Key</p>  <p>x1</p>	<p>(O) Inverted Plate</p>  <p>x1</p>	





Do not discard any of the packaging until you have checked that you have all the parts and the pack of fixings.

Assembly







Helpful advice before you begin:

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
3. Assemble this product on a soft surface.
4. To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.
5. Keep fittings out of children's reach.
6. Do not use any other tools other than those recommended to build this product.
7. Please do not use substitute parts. Use only additional or replacement parts supplied by Kettler.
8. In the unlikely event that this product has missing or damaged parts, please visit our website www.kettler.co.uk

Assembly




Assembly




Assembly


9



10




11




Assembly

12




Place part (A) (canopy) on
part (D) and reattach bolts.

13




Operating Instructions

1




2




Operating Instructions



3





The winding handle can be placed in adjacent hole to tilt canopy horizontally.




4



Operating Instructions







Parasol Wireless Speaker with LED Light



Functions

1. Bluetooth Switch
2. LED Light Power Switch
3. Unlock Button
4. LED Light
5. Charging Port



Unscrew and pull down middle section and attach the Wireless speaker here.

Charging:

- Charge for 2-4 hours for the 1st charge.
- Plug the adapter in the charging port and plug into the power supply (100-240V).
- We recommended 1.2amp maximum output. Anything over this continuous use could result in reduced life span of the battery.
- When charging the red light will light up and go off when fully charged.
- Always charge in a dry environment.


Warning:

- Wireless connectivity will turn off when not used for 15 minutes.
- The sound quality will be reduced when the battery is low.
- Use wirelessly for upto 8-10metre range. Any more than this will affect the sound quality.
- Only one device can be connected at any one time.
- Do not allow the speaker unit to get wet.
- Store in a dry place when not in use.

User guide:

- To turn on, hold down the wireless switch for 3 seconds.
- Turn on your device's Wireless function and search for "Kettler".
- The run time is approx. 6-10 hours.
- To turn the light on/off press the "LIGHT" button.





This parasol has UV50+ protection. What does that mean?

For example, a fabric with a UPF rating of 50 only allows 1/50th of the sun's UV radiation to pass through it. This means that this fabric will reduce your skin's UV radiation exposure by 50 times (98% UV block).

Hand wash canopy

The canopy can be carefully removed and washed via hand only. We advise putting back onto the frame to dry naturally.

For Your Safety

- This product may only be used for its intended purpose as furniture for residential properties.
- Check all components regularly for correct function, damage and loose connections especially at the start of the season and at 1-2 month intervals dependent on use.
- Damaged components may endanger your safety or shorten the life of the product. Replace all damaged parts immediately. Use only spare parts manufactured by Kettler. Should you wish to purchase spare parts, they can be ordered directly from: www.kettler.co.uk/shop
- Kettler will not be responsible for damaged caused by improper use.



Attention

- Whilst assembling this product keep out of the reach of children. (Choking hazard – contains small parts)
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around.
- Always dispose of packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- We reserve the right to make changes for technical reasons.



For more information view our
'How-To' and maintenance videos:
kettler.co.uk/how-to-guides



The symbol indicates that the
product should not be discarded as
unsorted waste but must be sent
to separate collection facilities for
recovery and recycling.

KETTLER

www.kettler.co.uk



PlanetMark



Warranty For Home Use

KETTLER parasols are covered by a
12 MONTH WARRANTY.

The warranty applies to domestic use only.

The warranty does not cover accidental
damage (including wind damage) or mis-use.

To validate your warranty, register at
www.kettler.co.uk and quote the product
code from the front of this booklet.