


KETTLER

4x3m Free Arm Parasol

PF34



IMPORTANT

PLEASE KEEP THIS BOOKLET FOR FUTURE REFERENCE.
THIS IS IMPORTANT INFORMATION REGARDING THE
USE AND CARE OF YOUR GARDEN FURNITURE.





















ASSEMBLY
TIME



PERSONS
REQUIRED


Parts List

<div><div>A</div> Parasol</div> <div></div> <div>x1</div>		<div><div>O</div> Protective Cover with 3 part supporting rod</div> <div></div> <div>x1</div>		
<div><div>B</div> Base Lever</div> <div></div> <div>x1</div>	<div><div>C</div> Adjusting Lever</div> <div></div> <div>x1</div>	<div><div>D</div> Allen Key 2.5</div> <div></div> <div>x1</div>	<div><div>E</div> Bolt M10 x 20mm</div> <div></div> <div>x5</div>	<div><div>F</div> Bolt M8 x 25mm</div> <div></div> <div>x2</div>
<div><div>G</div> Allen Key 6</div> <div></div> <div>x1</div>	<div><div>H</div> Allen Key 8</div> <div></div> <div>x1</div>	<div><div>P</div> USB Cable</div> <div></div> <div>x1</div>	<div><div>Q</div> Solar Panel</div> <div></div> <div>x1</div>	<div><div>R</div> Removable Battery pack</div> <div></div> <div>x2</div>
<div><div>I</div> Base (Frame)</div> <div></div> <div>x1</div>	<div><div>J</div> Weight Tank</div> <div></div> <div>x4</div>	<div><div>K</div> Base (Top)</div> <div></div> <div>x1</div>		
<div><div>L</div> Footcaps</div> <div></div> <div>x4</div>	<div><div>M</div> M6 x 12mm</div> <div></div> <div>x4</div>	<div><div>N</div> Spanner</div> <div></div> <div>x1</div>		

Helpful advice before you begin:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
3. Assemble this product on a soft surface.
4. To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.
5. Keep fittings out of children's reach.
6. Do not use any other tools other than those recommended to build this product.
7. Please do not use substitute parts. Use only additional or replacement parts supplied by Kettler.
8. In the unlikely event that this product has missing or damaged parts, please visit our website www.kettler.co.uk

Assembly




Assembly



2



Fill each tank completely with **kiln dried sand** and then add water. Position the tanks in the correct spaces when filled.




3




Assembly

4




5




Assembly

6




Operating Instructions

7




Operating Instructions

8



9





The power base and battery pack are connected by magnet.


- The battery pack should take approx. 4-5 hours to charge. Once charged the indicator light will light up.
- A full charge should last approx 6 hours.
- The battery pack should be stored in a dry location when not in use and must not get wet.
- The battery pack must not be stored/used below 0°C or above 45°C.

Operating Instructions

10





11




Operating Instructions



When not in use the parasol should have the night cover fitted.
The parasol should not be used and **MUST BE** taken down in windy conditions to avoid damage.
The parasol should be stored away in a dry environment when not in prolonged use.







Parasol Wireless Speaker with LED Light



Functions

1. Bluetooth Switch
2. LED Light Power Switch
3. Unlock Button
4. LED Light
5. Charging Port



Unscrew and pull down middle section and attach the Wireless speaker here.

Charging:

- Charge for 2-4 hours for the 1st charge.
- Plug the adapter in the charging port and plug into the power supply (100-240V).
- We recommended 1.2amp maximum output. Anything over this continuous use could result in reduced life span of the battery.
- When charging the red light will light up and go off when fully charged.
- Always charge in a dry environment.

Warning:




- Wireless connectivity will turn off when not used for 15 minutes.
- The sound quality will be reduced when the battery is low.
- Use wirelessly for upto 8-10metre range. Any more than this will affect the sound quality.
- Only one device can be connected at any one time.
- Do not allow the speaker unit to get wet.
- Store in a dry place when not in use.

User guide:

- To turn on, hold down the wireless switch for 3 seconds.
- Turn on your device's Wireless function and search for "Kettler".
- The run time is approx. 6-10 hours.
- To turn the light on/off press the "LIGHT" button.



Protective Cover Assembly



This parasol has UV50+ protection. What does that mean?

For example, a fabric with a UPF rating of 50 only allows 1/50th of the sun's UV radiation to pass through it. This means that this fabric will reduce your skin's UV radiation exposure by 50 times (98% UV block).

Hand wash canopy

The canopy can be carefully removed and washed via hand only. We advise putting back onto the frame to dry naturally.

For Your Safety

- This product may only be used for its intended purpose as furniture for residential properties.
- Check all components regularly for correct function, damage and loose connections especially at the start of the season and at 1-2 month intervals dependent on use.
- Damaged components may endanger your safety or shorten the life of the product. Replace all damaged parts immediately. Use only spare parts manufactured by Kettler. Should you wish to purchase spare parts, they can be ordered directly from: www.kettler.co.uk/shop
- Kettler will not be responsible for damaged caused by improper use.



Attention

- Whilst assembling this product keep out of the reach of children. (Choking hazard – contains small parts)
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around.
- Always dispose of packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- We reserve the right to make changes for technical reasons.



For more information view our
'How-To' and maintenance videos:
kettler.co.uk/how-to-guides



The symbol indicates that the product should not be discarded as unsorted waste but must be sent to separate collection facilities for recovery and recycling.

KETTLER

www.kettler.co.uk



PlanetMark



Warranty For Home Use

KETTLER parasols are covered by a
12 MONTH WARRANTY.

The warranty applies to domestic use only.
The warranty does not cover accidental
damage (including wind damage) or mis-use.

To validate your warranty, register at
www.kettler.co.uk and quote the product
code from the front of this booklet.