


Mixit low wide unit

Stock Code: 80324203 - 80324103 - 80324003


Thank you for purchasing this Mixit low wide unit. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



PRE-ASSEMBLY PREPARATION

Please ensure instructions are read in full before attempting to assemble this product.

Necessary Tools



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the John Lewis Helpline.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately **60 MINUTES** to assemble with **2 PEOPLE**.

















The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.



If you are missing some fittings (cams, dowels and screws) please contact our spare parts helpline on 0330 005 9435. Opening hours are 9am - 5pm Monday to Friday.

For all other queries, please call John Lewis Customer support on 0345 604 9049

Fittings checklist

<p>A</p>  <p>Metal dowel x 12</p>	<p>B</p>  <p>Cam lock x 8</p>	<p>BI</p>  <p>Long cam lock x 4</p>
<p>C</p>  <p>Wooden dowel x 12</p>	<p>D</p>  <p>Wedgefix housing x 8</p>	<p>E</p>  <p>Wedgefix dowel x 8</p>
<p>F</p>  <p>25mm Nail x 30</p>	<p>G</p>  <p>Nail guide x 1</p>	<p>GI</p>  <p>Levelling Wedge x 2</p>
<p>H</p>  <p>27mm Connector x 2</p>	<p>I</p>  <p>4MAx15 Connect. screw x 2</p>	<p>L</p>  <p>Support foot x 5</p>
<p>M</p>  <p>30mm Screw x 10</p>	<p>N</p>  <p>Spacer x 8</p>	<p>O</p>  <p>13mm Euro screw x 8</p>
<p>P P1 P2</p>  <p>Wall fixing set x 4</p>		


Parts checklist



Step by step assembly instructions


Step One

1. Attach 12x metal dowels (A) into the pre-drilled holes on top/bottom panels (1) as shown. Use a screwdriver to turn fitting (A) clockwise to fix.



Step Two


1. Place 8x cam lock (B) into the holes on side panels (4) as shown, arrow pointing towards the bolt.
2. Attach 8x wooden dowels (C) into the pre-drilled holes on side panels (4) as shown.
3. Fix 4x wedgexif dowels (E) into the holes on side panels (4) as shown.



Step by step assembly instructions


Step Three

1. Attach 8x wedgex housing (D) into the pre-drilled holes on shelves (3) as shown.



Step Four


1. Place 4x long cam lock (BI) into the holes on divider (5) as shown, arrow pointing towards the bolt. Ensure long cam lock (BI) is pushed down firmly to base of drill hole.
2. Attach 4x wooden dowels (C) into the pre-drilled holes on divider (5) as shown.
3. Attach 4x wedgex dowels (E) into the holes on divider (5) as shown.



Step by step assembly instructions


Step Five

1. Attach panels (5)(4) to top/bottom panels (1) as shown. Ensure metal dowels (A) and wooden dowels (C) are aligned correctly with the holes of matching parts before attaching.
2. Secure panels using a screwdriver to turn fitting (B) clockwise to fix.



Step Six


1. Position back panel (2) as shown, back panel holes indicate upper part.



Step by step assembly instructions


Step Seven

1. Attach back panel (2) onto back side of the unit using 30x nails (F), with the help of the nail guide (G).



Step Eight (only for base unit)


1. Attach support foot (L) onto bottom (1) using 30x screws (M).



Step by step assembly instructions


Step Nine

1. With help of an assistant, carefully stand up the unit upright.



Step Ten (only for base unit)


1. Use 2x levelling wedge (G1) to level the unit.



Step Eleven

Fittings have been supplied in order to join units together.

1. Place units together in their final position.
2. Decide position where to drill through using a $\text{Ø}5$ mm bit.
3. Push the Connector (H) into the hole and then screw Bolt (I) in from the other side, tighten with a screwdriver.



Step by step assembly instructions



Step Twelve (only for base unit)

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by use of two 'L' Brackets (P) fitted to the top side of the unit.

1. Attach the 2x brackets (P) onto the top side of the unit using 4x euro screws (O).
2. Pre-fix brackets (P) to wall, Wall plug and screw not included.
- 3,4. Adjust position using (P1), then attach it.
5. Insert cap (P2)

! IMPORTANT !

Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.
Wall plug and screw not included. See wall fixing guide at page 12.



Step by step assembly instructions



Step Thirteen (only for wall unit)

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by use of two 'L' Brackets (P) fitted to the top side of the unit.

1. Attach the 4x brackets (P) onto the top side of the unit using 8x euro screw (O).
2. Pre-fix brackets (P) to wall, Wall plug and screw not included.
- 3,4. Adjust position using (P1), then attach it.
5. Insert cap (P2)

! IMPORTANT !



Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.
Wall plug and screw not included. See wall fixing guide at page 12.




Step by step assembly instructions

Step Fourteen


1. Position the sheves (3) on the shelf support (E) as shown




Wall fixing - if in doubt seek professional advice



Wood
If fixing to wood make sure that it is not chipboard as screws can easily pull away from the core structure



Brick or Masonry
Use an appropriate wall plug provided you are sure your wall is sound.



Cavity wall
Special toggle wall plugs are needed. Seek expert advice.

Care and Maintenance

This product has been manufactured using modern manufacturing methods and materials.

To keep your product, looking at its best, we strongly recommend either dusting with a soft cloth, or the use of a damp (not wet) cloth and water containing no more than a 5% soap solution. Dry with a soft clean cloth.

Aggressive chemicals, such as wax furniture polish, abrasive cleaners, bleach or hypochlorate (chlorine) based cleaners, multi purpose cleaners, dilutes, acetone, alcohol and solvent based liquid product should NOT be used, as may result in damage.

Safety Instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving a heavy object to a new location it is completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

This product is designed to be fixed securely to a sound wall in the manner stated.

It must under no circumstances be used free-standing. No liability will be accepted for damage or injury caused by inadequate fixing or use without fixing.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SW1E 5NN
www.johnlewis.com