DANO 10 LIGHT LED PENDANT FITTING

IL3277

Thank you for buying this **Dano LED** pendant fitting.

Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

This product is Class II

Warnings

- * It is recommended that this fitting is installed by a qualified electrician.
- * This fitting should be fitted in accordance with IEE Wiring Regulations and the Building Regulations.
- * To prevent electrocution switch off at the mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electricity supply without your knowledge.
- * If you are in doubt please consult a qualified electrician.
- * To avoid damage to concealed wiring during installation, establish the direction of the supply cable before drilling fixing holes.
- * \F\ Indicates that the fitting is suitable for mounting on normally flammable surfaces.
- * This fitting should be fitted to a lighting supply with protected 5 amp fuse or equivalent circuit breaker.
- * Please note that this fitting incorporates fixed designated LED's which are non-replaceable and non-dimmable.

Instructions for use

- 1. Ensure the house electricity supply is off at the fuse board.
- 2. Before removing the existing rose, carefully note the position of each set of cables. If there are loop in cables then these must be terminated separately and not connected to the fitting.

This fitting is height adjustable at point of installation only. No attempt must be made to adjust the height once it has been attached to the ceiling. If adjustment is required at a later date the fitting must be isolated from the mains and removed from the ceiling first.


If you require the wires to be lengthened or shortened, push the inner metal tube that the wire passes through on the ceiling cup in on itself and then pull the wire back through. The tube is spring loaded and as soon as it is released the wire will be locked into position again.

- 3. Remove mounting bracket from fitting by undoing the screws located on the ceiling cup.
- 4. Using the bracket as a template, mark and then drill the fixing holes in the ceiling (ensure that the holes are drilled into a secure joist).
- 5. Attach mounting bracket to the mounting surface using suitable fixings. Do not attach fitting to mounting bracket at this stage. Take care not to damage wiring.
- 6. Lift the fitting close to supply cable and then make the electrical connections as follows:

Connect supply live (normally brown or red) to fitting live (marked "L") on the terminal block.

Connect supply neutral (normally blue or black) to fitting neutral (marked "N") on the terminal block.

Please note: No earth should be connected to any part of this fitting. If any earth wires are present please terminate these in a separate terminal block (not supplied) to ensure that continuity is maintained for the household earth circuit.



- 7. Excess cable must be carefully located inside ceiling cup or within the ceiling void. Fit the ceiling cup over the mounting bracket and secure in position using the screws removed earlier.
- 8. Attach the glass shades by carefully screwing each shade over the top of the lampholder section. Take care not to overtighten or allow the shades to collide as this could cause damage to the fitting.
- 9. Switch on the electricity supply at the fuse board.

Please retain this information leaflet for future reference

GENERAL INFORMATION

This fitting is designed for internal use only Do not use polish or abrasive cleaner – just a soft dry cloth.

