




## Box Desk

Stock number: 816 27601



H75 W100 D60 cm

Thank you for purchasing the Box desk. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

At John Lewis, we are committed to making great products possible.

From our in-house Design Team, to our Buyers, we work together to bring great designs to life.

Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell.

We are all committed to designing and developing products to the highest industry standards.

We hope you are happy with your product and welcome any feedback or comments you may have.


The John Lewis Team

## Tools required



**Time to assemble**  
45 minutes

**People to assemble**



# Important safety information

## Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

## Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

## Don'ts

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.




# Your Desk



Ref	Description	Dimensions	Qty
1	Desktop	962x600x18mm	1
2	Side Frame Left	750x600x19mm	1
3	Side Frame Right	750x600x19mm	1
4	Upper Rail-Front	962x19x19mm	1
5	Upper Rail-Rear	962x19x19mm	1
6	Lower Rail	962x19x19mm	1

# Fixtures and fittings



Fixtures and fittings  
supplied (actual size)

Ref	Description	Dimension	Qty	mm
<b>A</b>	Bolt for desktop and wall fixing bracket	M6x15mm	10	
<b>B</b>	Bolt for frame assembly	M8x35mm	6	
<b>C</b>	Washer	M8x16mm	6	

Fixtures and fittings  
supplied (not actual size)

Ref	Description	Dimension	Qty	
<b>D</b>	Wall fixing bracket	20x84x18x2mm	2	
<b>E</b>	Allen Key M4	4x55mm	1	

# Product assembly


Box Desk  
816 27601

## Step 1

Parts, fittings and tools

2 4 5 6

B C




Please ensure the rails are fixed as shown, and do not completely tighten bolts at this stage.

## Step 2

Parts, fittings and tools

3 B C




To allow for some tolerance for fixing the desktop, please do not tighten bolts completely at this stage.

### Step 3

Parts, fittings and tools

I A




After fixing the desktop, please tighten all bolts clockwise.

### Step 4



Fittings and tools

A D



## Step 5 – Wall fixing

Attach the bracket to the wall using the correct wall fixing (see page 9)



### Warning

Serious or fatal injuries can occur from furniture tipping over.

To prevent this furniture from tipping over, it must be permanently fixed to the wall.

## A guide to wall mounting and fixings







### Warning



In order to prevent overturning this product must be used with the wall attachment device provided. Wall fixing screws are not included, since different wall materials require different types of screws / fixings. Please ensure you use the correct screws / fixings for your type of walls and seek professional advice if you are not sure.

Installation shall be carried out exactly according to the instructions provided – otherwise a safety risk can occur if incorrectly installed. Failure of the product due to incorrect fixings is the responsibility of the installer.

**Important:** When drilling into the walls always check that there are no hidden wires or pipes etc.



### Types of walls

You can use one of the following types of wall plug if your wall is made of brick, breezeblock, concrete, stone or wood.

#### 1. General purpose wall plug

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general – purpose wall plugs can be used.

#### 2. Plasterboard wall plugs

For use when attaching light loads on to a plasterboard partitions.

#### 3. Cavity Fixing wall plug

For use with plasterboard partitions or hollow wooden doors.

#### 4. Cavity fixing – Heavy Duty wall plug

For use when fixing or supporting heavy loads such as shelving, wall cabinets and coat racks.

#### 5. Hammer fixing wall plug

For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

#### 6. Shield Anchor wall plug – Heavy Loads

For use with heavier loads such as TV and Hi-Fi speakers and satellite dishes etc.

### Care and maintenance

**Safety:** Periodically check all fittings and wall fixings to ensure they have not come loose and retighten as necessary.



## Care guide

### Care and maintenance

#### Melamine & Metal furniture

Your desktop is made from particle board with a wood structure melamine surface. The frame is made from steel with a powder coated finish.

#### How to care for your melamine/metal furniture

Furniture with a melamine or powder coated surface should be dusted with a dry cloth.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping

#### Safety instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Retain these instructions for future reference.

**Your feedback is very important to us and we would love to hear your comments on your new furniture. Please visit our website to leave a review. Thank you.**