

## Product information

- Outdoor use only
- Non-dimmable
- Replacement bulbs should be the same type and rating, available from John Lewis Partners or other established brands
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish
- Just use a damp cloth. Do not use abrasive materials as these will damage the finish. Take care when handling glass parts to avoid damage or injury
- Do not use this product if the shade is cracked or damaged.  
Do not use the product without the shade attached

## Aftercare and Troubleshooting

### You've switched on the light, but it's not working:

1. Check your power supply is switched on
2. Turn off the light and check that the bulb is inserted correctly
3. Check the bulb is still in working order

If there are technical issues with this product that you can't solve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.

## Specification

Max power: 2 x 15W LED E27 GLS bulb for maximum brightness.  
Lower wattages can be used.  
Rated input: 220 –240V, 50Hz  
Bulb not included  
IP rating: 44  
Weight: 3.96kg

## 5-year guarantee


At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 5-year guarantee.

## Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk).




# POTTER OUTDOOR WALL LIGHT USER GUIDE



John Lewis Plc  
171 Victoria Street  
London SW1E 5NN  
[johnlewis.com](http://johnlewis.com)



IP44



31/07/2023

Made in China

Please retain these instructions for future reference.



Product Code:  
70270201

**Thank you for purchasing this Potter outdoor wall light.  
Please read the instructions carefully before  
use to ensure safe and satisfactory operation  
of this product.**

## Warnings



This is a Class 1 product and must be earthed. Please read these instructions carefully before commencing any work. It is recommended that this fitting is installed by a qualified electrician. Install in accordance with the IEE Wiring regulations and the Building Regulations. To prevent electric shock switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge.

If you are in any doubt, please consult a qualified electrician.

This light fitting should be connected to a 5 amp fused circuit.

If replacing an existing fitting, make a note of the connections.


This product is rated IP44 and is suitable for outdoor use.

This product is suitable for installation on surfaces with normal flammability e.g. wood, plasterboard, masonry. It is not suitable for use on highly flammable surfaces (e.g. polystyrene, textiles).

For your safety, always switch off the supply before changing lightbulbs, cleaning or removing shades. Always take care when handling lightbulbs to avoid injury in case of breakage.

## Parts list

Qty


Parts list		Qty
Light fitting		1
Wall plugs		2
Screws		2

## Product assembly

1

Carefully unpack the carton, making sure all the parts are present before assembly. Before removing the existing fitting, carefully note the position of each set of wires.


2



Remove the shade (A) from the product by undoing top and bottom screws and washers. Save for refitting later. Remove the back plate (C) from the fitting by removing finials and rubber washers (B).

Using the wall plugs and screws provided in the fixing pack, secure the back plate to the wall. Take care to avoid damaging any concealed wiring and pipes.

3




Having identified the household wiring from your existing light fitting, connect to the outdoor rated connection block (D) inside the product in the following way.

Check that:  
You have correctly identified the house wires.

- The connections are tight.
- No loose strands have been left out of the connection block.
- Ensure the grommet is in place to maintain IP rating.

4



Re-attach the light fitting to the back plate (C) by locating the screw holes over the screws and replacing the rubber washers and the finials (B) and tightening them securely.

Fit the recommended bulbs.  
Refit the shade (A) onto the light fitting ensuring drain hole (E) is at the bottom. Refit top and bottom washers and screws and tighten to secure.